

Lovibond® Colour Measurement Tintometer® Group



Quinizarin in Marked Oils, Roadside Test, 10 - 100

Determine Quinizarin in Marked Oils as Prescribed by HM Customs & Excise



- Fast, Economical & Portable Visual Matching
- Two-Field Vision for Accurate Results
- Ability to Guarantee Constant Lighting Conditions

Part Number: 422310

Easy-To-Use Roadside Test

You can now determine quinizarin in marked oils as prescribed by HM Customs & Excise directly at the roadside with easy visual comparison.

Fast, Economical & Portable Visual Matching

The Comparator 2000+ is a flexible, modular system for Visual Colour Grading. Using a suitable comparator instrument and glass disc, you can quickly visually match the sample directly against the calibrated, colour stable glass standards.

Two-Field Vision for Accurate Results

Lovibond® comparator instruments include an integrated prism which causes the sample and comparison fields to overlap, allowing enhanced colour discrimination and matching. The prism is ultrasonically sealed to prevent contamination of the optics. Each individually graded glass standard represents a discrete step on the measurement range (as opposed to a continuous graduation), aiding colour discrimination and allowing great accuracy of results.

Ability to Guarantee Constant Lighting Conditions

An optional item for the Comparator 2000+ is the Daylight 2000 Lighting Unit. This is a standardised light source which guarantees you a constant lighting condition for accurate colour grading. This is particularly useful when the sample is very pale in colour. By using a Lovibond® lighting unit, you can be confident of uniform lighting conditions for colour matching, 24 hours a day and irrespective of ambient lighting.

Extended Shelf Life

The unique feature of Lovibond® test discs is that they incorporate coloured glass standards that are colour stable and not affected by UV light or extreme environmental conditions.

Please note, we cannot guarantee compatibility of discontinued Lovibond® Comparator 1000 disks with the Lovibond® 2000+ Comparator.

Industry

Oil and Gas

Application

Petroleum Oils and Waxes

Quinizarin in Marked Oils, Roadside Test, 10 - 100

The Comparator 2000+ is an easy-to-use, entry level colour measurement system that compares the colour of the sample directly against the colour of glass in a disc. All you need to do is rotate the disc to get the closest result to the scale.

Technical Data

Colour Type	Transparent
Portability	Portable

Delivery Scope

- Sturdy Case Including
- 1 x Lovibond® 2000+ Comparator
- 1 x 12v Car Adaptor Lead
- 1 x Comparator Daylight 2000+
- 1 x 4/43A Marked Oils Disc
- 2 x Extraction Tube Cal. (5, 10, 105 ml)
- 2 x Plastic Syringe (2ml)
- 1 x Butan-1-OL Solution (100 ml)
- 1 x Sodium Hydroxide 10% (100 ml)
- 1 x Instruction Card

Tintometer GmbH
Lovibond® Water Testing
Schleefstraße 8-12
44287 Dortmund
Tel.: +49 (0)231/94510-0
Fax: +49 (0)231/94510-30
sales@lovibond.com
www.lovibond.com
Germany

The Tintometer Limited
Lovibond House
Sun Rise Way
Amesbury, SP4 7GR
Tel.: +44 (0)1980 664800
Fax: +44 (0)1980 625412
sales@lovibond.uk
www.lovibond.com
UK

Tintometer China
Room 1001, China Life Tower
16 Chaoyangmenwai Avenue,
Beijing, 100020
Tel.: +86 10 85251111 App. 330
Fax: +86 10 85251001
chinaoffice@tintometer.com
www.lovibond.com
China

Tintometer South East Asia
Unit B-3-12, BBT One Boulevard,
Lebuh Nilam 2, Bandar Bukit Tinggi,
Klang, 41200, Selangor D.E
Tel.: +60 (0)3 3325 2285/6
Fax: +60 (0)3 3325 2287
lovibond.asia@tintometer.com
www.lovibond.com
Malaysia

Tintometer Brazil
Caixa Postal: 271
CEP: 13201-970
Jundiaí – SP
Tel.: +55 (11) 3230-6410
sales@tintometer.com.br
www.lovibond.com.br
Brazil

Tintometer Inc.
6456 Parkland Drive
Sarasota, FL 34243
Tel: 941.756.6410
Fax: 941.727.9654
sales@lovibond.us
www.lovibond.com
USA

Tintometer India Pvt. Ltd.
Door No: 7-2-C-14, 2nd, 3rd & 4th Floor
Sanathnagar Industrial Estate,
Hyderabad, 500018
Telangana
Tel: +91 (0) 40 23883300
Toll Free: 1 800 599 3891/ 3892
indiaoffice@lovibond.in
www.lovibondwater.in
India

Tintometer Spain
Postbox: 24047
08080 Barcelona
Tel.: +34 661 606 770
sales@tintometer.es
www.lovibond.com
Spain

Technical changes without notice
Printed in Germany

Lovibond® and Tintometer® are Trademarks of the Tintometer Group of Companies